

PAPERPLAINING

preparing the wallpaper paste



- preparation according to the label



- 3 tablespoon wallpaper paste mixed in a half liter water
wait a few minutes (s. label) - stirring it well - done.

Optional: optimize the properties of the wallpaper paste for mounting (heavier grade papers)

Test it before mounting the paper - if it can be easily removed!



1 tablespoon wood glue stiring in water (1-2 tablespoon)
diluted wood glue mixed with the done wallpaper paste.
a good consistency of the wallpaper paste = thick puree

Mounting

